

Instructions **NS26**



2. Hold the pairing button to turn into pairing mode

- with flashing led. 3.Set GuliKit controller to "windows-X" mode, hold the pairing button to turn it into pairing mode with flowing led.
- Ways of setting pairing mode on other controllers. The adapter gets paired to controller when leds are steady on. Then you are good to use the
- Switch Pro controller pairing guide :

Я ЫZ


Xbox controller pairing guide:





В





pairing mode with flashing led.

2. Next plug the adapter into USBA port on your console.

Note: Do not reverse step 1 and step 2. 3.Hold the pairing button on adapter to turn into

В ((

) [


(D) \otimes

((





. when



Plug GuliKit controller adapter into the USB port on Switch dock.
 Press and hold the pairing button on the adapter until you see flashing LED to get the adapter into


controller into pairing mode and get


w ((A)

Controller Button Mapping on Switch:

- \oplus В

Xbox, Xbox One, Xbox Series, Windows, ⊗ are registered trademarks of Microsoft® Inc. PS, PS4, ♣ are registered trademarks of SONY® Inc. Switch Pro, initendo, ∰ are registered trademarks of Nintendo® of America Inc.





Note: Note:

1. Do not unplug your original controller off the adapter, or your controller can not work.

2. The adapter supports auto pairing to your controller on this console next time even when you switch back from other consoles.

Use on Switch:

pairing mode. Turn your con

- \oplus

