GuliKit®



Elves Pro Controller

Enjoy gaming easier !

NS19

Thank you for choosing Gulikit products.

Gulikit is a design-driven brand of game accessories.

Everything we do is for breakthroughs and innovations.


We firmly believe in thinking differently and we strive to make gaming easier and more fun!



APG button

Setting button

Controller automatically shuts down in case of no any button action in 10 minutes.
Controller wakes up by pressing any one of A,B,X,Y and Mode buttons.


Working mode indicator
USB-C port
Charging and wire connection.
Charging indicator
Orange for charging,off when charge in full
Controller No.indicator
iOS
D
X
R
ZR
L
ZL
Pairing button
Press it 2 secons above for pairing
Mode button
Press button 2 seconds above for mode switch
Double clicks for shutdown,one click for power on.



How to pair GuliKit controller with Switch:

1. Go to controller setting on Switch as above photo indicated.
2. Press pairing button on controller 2 seconds and start pairing.
3. Pairing is completed once Switch shows successful connection to new controller.

Another way for controller connection.

Place Switch to Switch dock and set Switch to pairing mode,connect the controller to Switch dock by using the USB A to USB C cable,Switch will get connected automatically with the controller quickly after seconds, unplug the cable, and Switch is still paired wirelessly with the controller. Controller can be also used with the cable plugged as a wired controller.

How to pair GuliKit controller with computer:

1. Hold the mode button on controller to switch it to PC XINPUT or DINPUT mode.
2. Press the pairing button on controller 2 seconds to start pairing with scrolling LED indication.
3. Go to Bluetooth setting on computer and search new device, choose"GuliKit Controller" and connect.
4. Pairing is completed once it shows successful connection to new controller.

It's same way as above to pair GuliKit controller with Android devices.

Wired connection is recommended if your computer has no Bluetooth:

Switch to the right mode on the controller for your computer, connect the controller and computer with the USB C to USB A cable.

USB A port on the backside of host computer is recommended if it is a desktop.

* DINPUT is the old connection protocol on Windows and it is recommended to play retro games on Windows or simulator. Mostly it is XINPUT mode for new games on Windows now.

How to pair GuliKit controller with iOS13：

1. Hold the mode button on controller to switch it to iOS mode.
2. Press the pairing button on controller 2 seconds to start pairing with scrolling LED indication.
3. Go to Bluetooth setting on iOS and search new device, choose"Xbox Wireless Controller" and connect.
4. Pairing is completed once it shows successful connection to new controller.

Note:Only the games that support MFI controllers can support the controller to work well in gaming.



APG button (Auto Pilot Gaming)

APG activation: Press learning button 3 seconds to start learning with a long vibration,controller will then record all the operations before the button is pressed again to stop recording or auto stop when time runs up to 10 minutes.

There is a short vibration when recording is completed.
It can record operations upto 10 minutes.

Auto operation:
Controller starts auto operation one time
for what it has learned by one click of learning button.

Double clicks will let it run auto operation continuesly.

Any button press except the stick will stop auto operation.

SHARE


(Share your Learning Records for Autopilot gaming to friends now.)

Turn on your controller,press the Gear button and Autopilot button to turn the controller into Read/Write mode,connect controller to PC with a USB datacable, a flashdrive "GuliKit dat" will show up.

and you will see a file“Auto.apg”which is the learning records for autopilot gaming. You may copy it and share to your friends,and also you may copy others to replace yours in this drive.

* Note: controller auto power off after Auto.apg replacement is completed. You may also click the mode button to turn off controller.

+ below means holding the setting button and pressing other buttons.




Modes of repeated shooting:

1. 10 seconds Repeated shooting. Hold button to start 10 seconds repeated shooting with one vibration indication and release button to stop.
2. Auto repeated shooting. Press button once to start auto repeated shooting with two vibrations indication and press again to stop.
3. Stop repeated shooting mode with a long vibration indication.



Function :

1. Buttons function switch with one vibration indication.
2. Stop buttons function switch with a long vibration indication.




VLA (Vibration Level Adjustment)

Up for adding vibration,down for reducing vibration.
4 levels vibration adjustment. The lowest level is vibration off.



Clear all current mode Settings.

Long vibration once for clearing completion.



MSA (Motion Sense Aiming)

Levels of gyro assisted aiming:

1. Low sensitivity,once vibration.
2. Medium sensitivity,twice vibrations.
3. High sensitivity, three times vibrations.
4. Cancel assist,once long vibration.



TSA
(Thumbsticks Sensitivity Adjustment)

1. Set stick sensitivity to 60%,once vibration.
2. Set stick sensitivity to 30%,twice vibrations.
3. Cancel setting,once long vibration.

R3 L3 stands for buttons of pressing stick down.

Questions & Answers:

- **What does it mean when the mode LED is blinking?**

  It indicates low battery when the mode LED is blinking and the controller needs recharging.

- **How should I do if I can not figure out what settings I have made on the controller?**

  You may clear all previous settings and make new settings you want by pressing ⚙ button and ⊖ button on controller.

- **Is there a way to restart the controller if the controller doesn't give any response in gaming while it still has power?**

  Controller can be reset by pressing the button in the back hole with a slim tool like toothpick.

- **How should I do if ZR, ZL buttons don't work well?**

  Double click the mode button to close the controller and then click once to open it.
  The controller will start a newcalibration for ZR,ZL buttons automatically to solve this.

- **How should I do if there are a few errors in the long regaming for the learning function?**

  Due to the wireless transmission, there might be signal frame loss in gaming and some small differences in same operations may occur. A Blocking Calibration can be made to solve this.For instance,Set Mario to keep going for one more second when it's stuck somewhere in gaming.

Product specification:

Brand: GuliKit
Product name: Elves PRO Controller
Part number: NS19
Input port: USB-C
Transmission distance: 10 Meters
Frequency range: 2.402GHZ - 2.480GHZ
Supported Platforms: Switch、PC X-INPUT、iOS13、PC D-INPUT / Android
Input voltage: 5V
Input current: 500mA
Cell capacity: 720mAh

RoHS

Made in China
www.gulikit.com

GuliKit®



谷粒精灵Pro手柄

让游戏触手可及

NS19

感谢您选择谷粒产品


谷粒是设计驱动型的游戏周边品牌，
我们做的每件事，都是为了突破和创新，
我们坚信应该用不同的方式思考，
我们努力使游戏更加轻松、有趣！



学习键

设置键

手柄没有任何按键动作，10分钟自动关机。
A、B、X、Y、模式键 中任意按键按下均可唤醒开机。


工作模式指示灯
USB-C接口
充电、有线连接。
充电指示灯
橙色 充电中，充满灯灭。
手柄号指示灯
iOS
D
X
R
ZR
L
ZL
模式按键
长按两秒以上切换模式
双击关机，单击开机。
配对按键
长按2秒以上开始配对。



switch手柄配对方法1：

1. switch进入手柄设置页面，如上图所示。
2. 长按手柄配对按键2秒，指示灯滚动，开始配对。
3. 界面显示连接新的手柄，配对完成。

switch手柄配对方法2：

手柄调到switch模式，插上附送的数据线，插到底座上的USB接口，游戏机放上底座，即会自动配对成功。
拔掉数据线，即可正常使用，也可以插着数据线有线模式使用。

电脑无线配对方法（需要电脑有蓝牙适配器）：

1. 手柄长按模式键，切换到PC XINPUT或者DINPUT。
2. 长按手柄配对按键2秒，指示灯滚动，开始配对。
2. 在电脑蓝牙设置里添加搜索设备，添加“GuliKit Controller”设备。
3. 界面显示连接到新手柄，配对完成。

安卓同上。

电脑有线模式使用：

手柄调到对应模式，插上附送的数据线，插到电脑USB接口，如果是台式机，建议插到主机背后USB接口。

注：DINPUT是老的手柄协议，如果玩一些老游戏或者模拟器建议使用，新游戏几乎都是支持XINPUT协议。

iOS13无线配对方法：

1. 手柄长按模式键，切换到iOS图标。
2. 长按手柄配对按键2秒，指示灯滚动，开始配对。
2. 在iOS蓝牙设置里添加搜索设备，添加“Xbox Wireless Controller”设备。
3. 界面显示已连接到手柄，配对完成。

注：需要游戏支持MFI手柄才可以在游戏中正常使用。



学习键

开始学习:长按3秒，长震动一下记录开始，然后会记录接下来所有按键动作，再次短按下学习键或者时间到10分钟，震动一下，记录完成。最长记录时间10分钟。

开始使用：
短按一次学习键，就自动重复已经记录下的动作一次。
双击学习键一直重复。

中途按其他任意键取消功能（摇杆除外）。


分享

学习键内容分享功能说明：

手柄开机状态，按着"设置键"不松，再按一下"学习键"，进入APG读写模式，插入USB数据线到电脑，可以看到名为“GuliKit dat”的U盘，U盘根目录“Auto.apg”就是APG文件，可以随意拷出备份、分享。也可以写入APG文件覆盖原来文件。

* 写入完成手柄会自动关机，也可以按“模式键”关机。

以下 + 的意思是按着设置键不松手的同时，再按其他功能键。



连发

连发等级：


1. 连发（每秒10次），按住按键时有效，松开停止。震动一次。
2. 自动连发，按一次按键，持续连发，再按一次停止。震动两次。
3. 取消连发。长震一次。



A-B X-Y键互换位置

位置：

1. 互换位置，震动一次。
2.取消互换位置，长震动一次。




震动力度调节

往上是增加，往下是减小，共4档调节，最低档为取消震动。



清除所有设置

长震动一次，清除完成。



体感辅助瞄准

辅助等级：

1. 低灵敏度，震动一次提醒。
2. 中等灵敏度，震动两次提醒。
3. 高灵敏度，震动三次提醒。
4.取消辅助，长震动一次 提醒。



摇杆灵敏度调节

1. 灵敏度降低到60%，震动一次提醒。
2. 灵敏度降低到30%，震动两次提醒。
3. 关闭调节，长震动一次提醒。

R3 L3是摇杆往下按的按键。

问答：

- 手柄模式指示灯为什么闪烁？
  模式指示灯闪烁是手柄电量低提示，手柄需要充电了。

- 手柄按键乱了，记不得设置了什么，怎么办？
  按住 ⚙ 同时按 ⊖ 键，即可清除所有设置。

- 手柄有电，按任何按键都没响应了，怎么办？
  用牙签等细物插到手柄背后中心位置复位孔内按动，即可强行关机。

- ZR ZL键不准了，怎么办？
  双击模式键关机，不要碰到ZL ZR键，开机会自动校准ZR ZL键。

- 学习键长时间回放的时候有一点误差，怎么办？
  因为数据传输的原因，按键动作可能会掉帧，出现每次重复时有差异问题，可以尝试游戏中卡边或者停顿1秒校正。
  例如：马里奥U，卡在走不动的位置，继续走1秒。

产品参数:

品牌：谷粒
产品名称：精灵PRO手柄
型号：NS19
输入接口：USB-C
传输距离：10米
频率范围：2.402GHZ - 2.480GHZ
支持平台：Switch 、PC X-input、iOS13、PC D-input / 安卓
输入电压： 5V
输入最大电流： 500mA
电芯容量：720mAh

FC CE RoHS

Made in China
www.gulikit.com